



NOTES:

- GENERALLY FOR ROOF PITCH OF 7:12 OR GREATER.
- SIP SCREW FASTENERS TO BE FLUSH WITH PANEL SKINS. DO NOT OVERSCREW SIP SCREW FASTENERS.
- VAPOR RETARDER/SIP SEAM TAPE RECOMMENDED ON INTERIOR OF PANEL WHEN MANDATED BY CODE OR CLIMATIC CONDITIONS.



**SURETIGHT**  
INSULATED PANELS

BUILD SMARTER. LIVE BETTER.

SHEET TITLE:

ROOF RIDGE - OVERLAY

SCALE:

NTS

LAST UPDATED:

12-06-05

SHEET NO:

SIPS-16